

# INSTALLATION & OPERATING INSTRUCTIONS



## MODEL 67060 SAVE THESE INSTRUCTIONS

**WARNING – The Surge Guard Model 67060 will provide protection even if there is a break in the ground wire in the supply power circuit or the internal circuit in the water craft. When using electric appliances, basic precautions should always be followed, including:**

- Read all instruction before using the appliance.
- To reduce risk of injury, close supervision is necessary when an appliance is used near children.
- Do not connect any electrical cord longer than 250 feet to the Surge Guard unit to avoid the possibility of nuisance tripping.
- This device is to be used on electrical distribution systems 120V/30A 60Hz only.
- Ground fault circuit interrupters do not protect against electrical shock resulting from contact with both line and neutral wires of the electrical circuit.
- The Surge Guard Model 67040 is designed as a protective device, do not use as an “on and off” switch.

### INSTALLATION INSTRUCTIONS

#### PLEASE READ THESE INSTRUCTIONS CAREFULLY.

In the event you have any questions concerning use or care of this product, please contact the sales department at Southwire Company, LLC.

### MODEL 67060

#### Installation Procedure

1. Plug the Surge Guard Model 67060 into an approved 120V/30A marine power receptacle.
2. Press and release the reset button. Verify that the Green light is visible.\* This indicates power is available to the watercraft.
3. Press the test button. Verify that the Green light is not visible.
4. Press and release the reset button. Verify that the Green light is visible.
5. Power is available. Operate equipment in your watercraft normally.

*\* If the unit is in the reset condition when plugged into the power receptacle, then the green light will be immediately visible.*

#### Warning

1. If the unit with contacts closed fails to trip when test button is pressed (Green light fails to extinguish), the device is not operating properly and should be returned to the point of purchase for replacement (see warranty information).
2. If the product tests properly without a load applied, but trips each time the watercraft load is applied, a current leakage exists and should be repaired or replaced as soon as possible (see warranty information). **DO NOT BYPASS THE SURGE GUARD UNIT IF THIS CONDITION OCCURS. A REAL SHOCK HAZARD MAY EXIST.**

**For technical assistance, please call 1-800-780-4324 x 20311**

Manufactured by Southwire Company, LLC, 4525 140th Avenue North, Suite 900, Clearwater, Florida 33762

© 2017 Southwire Company, LLC. All rights reserved.

\* Trademark of Southwire Company, LLC. Registered in the United States.

505-00060B

# INSTALLATION & OPERATING INSTRUCTIONS



## MODEL 67060

### TROUBLESHOOTING

**Watercrafts, new and old, can have loose, faulty, or even incorrect wiring which could be potentially dangerous. In the event there is a leakage of current caused by one or more of the above conditions, the Surge Guard Model 67040 will cut the flow of electricity. Should this happen, follow the procedures below to isolate the cause; however, Southwire recommends that all electrical repairs be done by a certified technician.**

1. Unplug the watercraft from the Surge Guard unit and push the reset button. If the unit trips immediately after reset, the problem is in the Surge Guard unit and it should be returned for repair or replacement (see warranty information). However, if the Surge Guard unit holds the set, continue on to step 2.
2. Turn off all the watercraft circuit breakers and plug the watercraft power cord into the Surge Guard unit. If the unit trips, the problem is in the cord and/or the connection supplying the watercraft. However, if the unit does not trip continue to step 3.
3. Turn on each circuit breaker one at a time until the Surge Guard unit trips. You have now isolated a circuit with leakage.
4. Unplug all appliances connected to the bad circuit and reset the circuit breaker and the Surge Guard unit. If the unit trips, then the problem is in the watercraft wiring. Should the Surge Guard unit not trip, see step 5.
5. Plug in each appliance until the Surge Guard unit trips. The appliance that causes the trip has a current leakage and should be repaired or replaced.

### WARRANTY INFORMATION

**Southwire Company, LLC warrants that its devices are free from defects in materials and workmanship for a period of one year from the date of original purchase. This one year warranty is in lieu of all other warranties, obligation, or liabilities expressed or implied by the company. Any properly installed device that proves defective in normal use will be repaired or replaced at Southwire's option provided the unit is returned through an authorized Southwire dealer or representative or ship the unit directly to Southwire following the procedure below:**

1. Contact Southwire Customer Support at 1-800-780-4324 to obtain a Return Materials Number.
2. Properly package returned unit.
3. Display Return Materials Number on outside of box.
4. Include Proof of Purchase, including date of purchase.
5. Supply full written description of the problem.
6. Specify your name, address, and daytime phone number.
7. Ship unit postage prepaid directly to: **Return Materials Department - Southwire Company, LLC  
4525 140th Avenue North, Suite 900 - Clearwater, Florida 33762**

**Any questions regarding this warranty, please contact Southwire by phone at 1-800-780-4324**

Warranty is void if the device has been altered, misused and/or abused in any way. Southwire cannot assume responsibility for customer alterations, acts of God, or any other factors not under the control of Southwire. Southwire cannot assume responsibility for damage in handling of shipment. Southwire shall have no responsibility for installation of this device or for any personal injury, property damage, any incidental, contingent, or consequential damages of any kind resulting in defects or failure of the unit to function in the event of a ground fault in the circuit it is protecting. Implied warranties (if any) including but not limited to implied warranties of fitness for a particular purpose and merchantability are limited in duration to a period ending one year from the date of original customer purchase. The exclusive remedy for breach of the limited warranty contained herein is the repair or replacement of the defective product at Southwire's option. In no case shall Southwire's liability under any other remedy prescribed by law exceed the purchase price. Some states do not allow the exclusion or limitation of incidental or consequential damages or allow disclaimers or modifications of or limitation on how long an implied warranty lasts, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.